

1. PERFORMANCE


- 1) Measuring range : 2-60 ppm
Number of pump strokes : 2 (200mℓ)
- 2) Sampling time : 3 minutes/2 pump strokes
- 3) Detectable limit : 0.5 ppm
- 4) Shelf life : 2 years
- 5) Operating temperature : 0 ~ 40 °C
- 6) Temperature compensation : Necessary (See "TEMPERATURE CORRECTION TABLE")
- 7) Reading : Direct reading from the scale calibrated by 2 pump strokes
- 8) Colour change : Yellow → Pale blue

2. RELATIVE STANDARD DEVIATION

RSD-low : 15 % RSD-mid. : 10 % RSD-high : 10 %

3. CHEMICAL REACTION

Chromium oxide is reduced.



4. CALIBRATION OF THE TUBE

DIFFUSION TUBE METHOD

5. INTERFERENCE AND CROSS SENSITIVITY

Substance	Interference	Coexistence
Alcohols	Similar stain is produced.	Higher readings are given.
Aliphatic hydrocarbons (more than C ₃)	Whole reagent is changed to dark Brown.	∕
Halogenated hydrocarbons	∕	∕
Esters	∕	∕
Aromatic hydrocarbons	∕	∕

TEMPERATURE CORRECTION TABLE

Tube Readings (ppm)	Corrected Concentration (ppm)				
	0 °C (32 °F)	10 °C (50 °F)	20 °C (68 °F)	30 °C (86 °F)	40 °C (104 °F)
60	88	70	60	54	48
40	54	46	40	36	32
20	28	24	20	18	16
10	14	12	10	9	8
5	7	6	5	4	3
2	2	2	2	2	2